



### How to sample powders or granules out of a pressurized pipe transfer ?

 **FlowControl**® samplers give the solution :

- Easy installation
- Reduce maintenance
- Hygienic operation
- Representative sampling
- Pressure up to 3.5 bar



.....  
 **Description - FlowControl**® is equipped with :

- 1 SS M fitting 1" (DN 25) to be welded on your pipe
  - 1 air pinch valve with rubber sleeve FDA & BGVV certified or any other valve optional
  - 1 SS transfer hose
  - 1 HDPE bottle - sampling volume : 1 or 2 liters
  - 1 PTFE bottle adaptor with vent outlet
  - 1 sterile air filter in PP 1/8" with membrane PTFE 0.2µ
  - 1 control cabinet with PLC allowing representative sampling on defined duration optional
- .....



